

XDECT 7005WP Waterproof Accessory Handset Owner's Manual

What's in the box?



XDECT 7005WP waterproof accessory handset
and water resistant charger

Not pictured:

- Factory installed rechargeable battery
- Belt clip

AC adapter
(AAD-6005(M))



Need Help? Get answers at our website: www.uniden.com.au for Australian model or www.uniden.co.nz for New Zealand model.

Important Safety Precautions!

When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:

- ♦ The charger is NOT waterproof: Do not use or place the charger near water (e.g., near a bath tub, wash bowl, kitchen sink or laundry tub, in a wet basement or near a swimming pool).
- ♦ If the charger falls into the water, unplug the AC adapter before removing it from the water. After you remove the charger from the water, contact Customer Service (see our website for contact information).
- ♦ Wipe excess water off of the handset before returning it to the charger.
- ♦ Avoid using a telephone (other than a cordless type) during an electrical storm. There may be a remote risk of electric shock from lightning.
- ♦ Do not use the telephone to report a gas leak in the vicinity of the leak.
- ♦ Use only the power cord and batteries indicated in this manual.
- ♦ Do not dispose of batteries in a fire. They may explode. Check with local codes for possible special disposal instructions.
- ♦ Do not place the handset in any charging cradle without the battery installed and the battery cover securely in place.

SAVE THESE INSTRUCTIONS!

Understanding the Waterproof Handset

- ◆ The handset complies with JIS7 water submersion specifications. It can remain submerged under 1m of water for up to 30 minutes without damage or loss of functionality.
- ◆ If the handset falls into water, just remove it; you can continue using the handset as normal.
- ◆ The handset will still receive calls even if it is under water, but you probably won't be able to hear the ringer or the earpiece. To avoid any accidents, do not try to use the handset while it is still under water.
- ◆ If you notice that the sound is distorted after your handset is submerged in water, there might still be water around the speaker and microphone. Just shake the handset to clear the water, and the sound should return to normal.
- ◆ Don't place the handset where it will be subjected to direct sunlight for long periods of time.

Installing Your Handset

Charge the Battery

The handset's rechargeable battery is already installed. Before you can charge the battery, you have to power it on.

- 1) Remove the cardboard spacer.
- 2) Press the power on/off (activation) pin according to the directions on the label.
- 3) Remove the label once the handset is powered on.



Save the power on/off pin in case you need to change the handset's power status later (i.e., to power off the handset when it will not be used for a long time). Use the plastic power on/off pin or a blunt-tipped object like an uncurled paper clip to press the power on/off toggle through the rubber seal. Do not use a sharp object; sharp objects might puncture the rubber seal and jeopardize the handset's waterproof status.

- 4) Connect the AC adapter to the charger's **DC IN 9V** jack and set the cord into the notch. (This adapter might already be connected.)
- 5) Plug the other end of the adapter into a standard 240V AC power outlet.

- 6) Place the handset in the charger with the display facing forward. The display on the handset should turn on.

If...	Try...
the handset display does not turn on	<ul style="list-style-type: none"> - Checking the AC adapter connection. - Seeing if the outlet is controlled by a wall switch. - Check handset activation at step 2 above.

Charge the handset completely (about 16 hours) before using it.

Registering to a Base

The accessory handset won't work until you register it to a base!

Compatible Bases

This handset is designed for use with Uniden's XDECT 7015 and XDECT 7055 bases. Other compatible Uniden bases include the SSE25, SSE27, DECT 2015 and DECT2035 models. Some features may not be available when using the XDECT 7005WP with these other bases. For the most up-to-date list of which bases this handset is compatible with, see our website.

Registration Methods

If the other base has an LCD display:	If the other base DOES NOT have an LCD display:
<ol style="list-style-type: none"> 1) On the base, open the menu. 2) Select <i>Register Handset</i>. The display should say <i>Handset Registering</i>. 	<ol style="list-style-type: none"> 1) Disconnect the base AC adapter. 2) On the base, press and hold FIND while you reconnect the adapter.
<ol style="list-style-type: none"> 3) On the handset, press and hold HASH (#) until the display says <i>Handset Registering</i> (about 2 seconds). 	

After about 30 seconds, the handset display should say *Registration Complete*.

Test the connection

Pick up the handset and press **TALK/FLASH**. Make sure you get a dial tone.
(Press **END** to hang up.)

If...	Try...
- you don't hear a dial tone - the display says <i>Registration Failed</i>	Making sure the handset is fully charged, then trying again.

How to De-Register the Handset (for Registering to another base)

- 1) On the handset, press and hold **END** and **HASH(#)** until the System Reset menu appears (about 5 seconds).
- 2) Select *Base Unavailable*.
- 3) When the phone asks you to confirm, select *Yes*. The handset deletes its own link without contacting the base.

Using the Belt Clip

To attach the belt clip

Line up the holes on each side of the handset. Insert the belt clip into the holes on each side of the handset. Press down until it clicks.

To remove the belt clip

Pull either side of the belt clip to release the tabs from the holes.

Important Information

- ◆ Because the handset adapts to the base, the exact features and operation of the handset will vary slightly depending on which base you register the handset to. Refer to the user guide for the base you're registering the handset to for feature descriptions.
- ◆ All features and operation for the handset are described in the owner's manual for one of the bases listed under the *Compatible Bases* section.
- ◆ Owner's manuals for all Uniden phones are available on our website for free downloading.

Specifications

AC Adapter	Part number	Input Voltage	Output Voltage
	AAD-600S(M)	240V AC, 50 Hz	9V DC@ 210mA
Battery pack	Part number	Capacity	
	BT-694s	500mAh, 2.4V DC	

- ◆ Use only the supplied AC adapter.
- ◆ Be sure to use the proper adapter for the base and any chargers.
- ◆ Do not place the power cord where it creates a trip hazard or where it could become chafed and create a fire or electrical hazard.
- ◆ Do not place the unit in direct sunlight or subject it to high temperatures.

Battery Information

- ◆ Fully charged, the battery should provide about 8 hours of talk time and about 7 days of standby time. For best results, return the handset to the cradle after each call to keep it fully charged.
- ◆ Keep an eye on the battery status icon. When the battery gets too low, the handset shows a low battery alert. If you hear a strange beep during a call, check the display: if you see the low battery alert, finish your conversation as quickly as possible and return the handset to the cradle. If the handset is in standby, none of the keys will operate.
- ◆ With normal use, the battery should last about one year. Replace the battery when the talk time becomes short even when the battery is charged. To buy a replacement battery, visit our website for contact information.

Replace the Rechargeable Handset Battery Pack

Follow these steps to replace the battery:

- 1) Unscrew the four screws holding the battery cover and remove it.
- 2) Remove the old battery pack from the battery compartment.
- 3) Line up the new battery's connector with the jack inside the battery compartment (the connector only fits one way).
- 4) Push the connector in firmly. Tug on the battery wires gently to make sure you have a good connection.

- 5) Before replacing the battery cover, check the rubber seal located on the under side of the cover: make sure that the seal is set in the groove and that there is no foreign matter under the seal.

If the rubber seal appears worn, nicked, or dried out, you must replace it. New seals are available through the Parts Department (see our website for contact information).

- 6) Replace the battery cover; use the four screws to secure the cover to the back of the handset.

Rechargeable Nickel-Metal-Hydride Battery Warning

CAUTION! Risk of explosion if battery is replaced by an incorrect type! Dispose of used batteries according to the instructions. Do not open or mutilate the battery. Disconnect the battery before shipping this product.

- ♦ This equipment contains a rechargeable Nickel-Metal-Hydride (Ni-MH) battery.
- ♦ Do not short-circuit the battery.
- ♦ The rechargeable battery contained in this equipment may explode if disposed of in a fire.
- ♦ Do not charge the battery used in this equipment in any charger other than the one designed to charge this battery as specified in the owner's manual. Using another charger may damage the battery or cause it to explode.

Rechargeable batteries must be recycled or disposed of properly.

Uniden works to reduce lead content in PVC coated cords in our products and accessories.

One-Year Limited Warranty

IMPORTANT Satisfactory evidence of the original purchase is required for warranty service

Please refer to our Uniden website for any details or warranty durations offered in addition to those contained below.

Warrantor

The warrantor is either Uniden Australia Pty Limited ABN 58 001 865 498 ("Uniden Aust") or Uniden New Zealand Limited ("Uniden NZ") as the case may be.

Terms of Warranty

Uniden Aust/NZ warrants to the original retail purchaser only that the XDECT 7005 WP ("the Product"), will be free from

defects in materials and craftsmanship for the duration of the warranty period, subject to the limitations and exclusions set out below.

Warranty Period

This warranty to the original retail purchaser is only valid in the original country of purchase for a Product first purchased either in Australia or New Zealand and will expire one (1) year from the date of the original retail sale.

If a warranty claim is made, this warranty will not apply if the Product is found by Uniden to be:

- (A) Damaged or not maintained in a reasonable manner or as recommended in the relevant Uniden Owner's Manual;
- (B) Modified, altered or used as part of any conversion kits, subassemblies or any configurations not sold by Uniden Aust or Uniden NZ;
- (C) Improperly installed contrary to instructions contained in the relevant Owner's Manual
- (D) Repaired by someone other than an authorized Uniden Repair Agent in relation to a defect or malfunction covered by this warranty; or
- (E) Used in conjunction with any equipment, parts or a system not manufactured by Uniden.

Parts Covered

This warranty covers the Product and included accessories.

User-generated Data

This warranty does not cover any claimed loss of or damage to user-generated data (including but without limitation phone numbers, addresses and images) that may be stored on your Product.

Statement of Remedy

If the Product is found not to conform to this warranty as stated above, the Warrantor, at its discretion, will either repair the defect or replace the Product without any charge for parts or service. This warranty does not include any reimbursement or payment of any consequential damages claimed to arise from a Product's failure to comply with the warranty.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

This warranty is in addition to and sits alongside your rights under either the COMPETITION AND CONSUMER ACT 2010 (Australia) or the CONSUMER GUARANTEES ACT (New Zealand) as the case may be, none of which can be excluded.

Procedure for Obtaining Warranty Service

Depending on the country in which the Product was first purchased, if you believe that your Product does not conform with this warranty, you should deliver the Product, together with satisfactory evidence of your original purchase (such as a legible copy of the sales docket) to Uniden at the addresses shown below. You should contact Uniden regarding any compensation that may be payable for your expenses incurred in making a warranty claim. Prior to delivery, we recommend that you make a backup copy of any phone numbers, images or other data stored on your Product, in case it is lost or damaged during warranty service.

UNIDEN AUSTRALIA PTY LTD

Service Division
345 Princes Highway,
Rockdale, NSW 2216
Phone number: 1300 366 895
Email address: custservice@uniden.com.au

UNIDEN NEW ZEALAND LTD

Service Division
150 Harris Road, East Tamaki
Auckland 2013
Phone number: (09) 273 8377
Email address: service@uniden.co.nz

For more exciting new products please visit our website:
Australia: www.uniden.com.au
New Zealand: www.uniden.co.nz

Uniden[®]