



Quick-Start Guide

App Cam XLight/X55/X56

Wireless IP Camera

Use this Quick-Start Guide to connect the camera to the network and for basic installation and setup procedure. For more detailed instructions refer to the online Owner's Manual on the Uniden website www.uniden.com.au. This quick start guide is for reference only. Slight difference may be found in user interface.

In the Box

Model	App Cam XLight	App Cam X55	App Cam X56
			
QSG	1	1	1
Power Adapter	1	1	1
Power Cable	-	-	1
Mounting Screw Kit	1	1	1
Installation Position Map	1	1	1
Mounting plate	-	-	1
Pry Bar	1	-	-

If any item is missing or damaged, contact your place of purchase immediately. **Never use damaged products!**

Need help? Get answers at our website:
www.uniden.com.au for Australian model


Important Safety Instructions

1. Do not drop, puncture or disassemble the camera.
2. DO NOT expose the camera to excessive water or moisture.
3. Never tug on the power cable to unplug from the power outlet. Always grasp the AC adapter when unplugging.
4. Do not expose the camera to high temperature or leave it in direct sunlight. Doing so may damage the camera or cause camera temporary malfunction.
5. For your own safety, avoid using the camera or power off the camera when there is a storm or lightning.
6. Remove the power adaptor during long periods between usages.
7. Use only the accessories and power adaptors supplied.

Quick Connect for the Camera

1. Power the power to the camera with the supplied power adapter. Give 2 minutes for the camera to boot up properly. Please make sure that the camera green LED indicator is flashing green on the camera LED indicator
2. Activate/press the **WPS** button on your router and also quickly press the **WPS** button on the camera
or
You can also connect the camera (except XLight) to a router with an Ethernet cable (not supplied).
3. When the camera successfully connected to the internet, the camera LED indicator will stay solid green.
4. If you face any difficulty connecting the camera to the WiFi, please reset the camera by press and hold the reset button for 10 seconds and try again.

Getting to know your App Cam XLight



Note:

The top cap can be opened with the pry bar included in the kit.

Press the **Reset/WPS** button to enable WPS.

Press and hold the **Reset/WPS** button for 10 seconds to reset the camera.

App Cam XLight Installation


Step 1: Mark and drill holes on the installation surface (wall or ceiling).

Step 2: Insert the expansion bolt into the hole.


Step 3: Open the bracket and pull the power cable through the cable tray on the bottom of the bracket.

Step 4: Align the screw holes on the bracket to those on the mounting surface, then fasten the installation screws.

Step 5: Secure the other half of the bracket to the camera, then adjust the power cable and secure the bracket.



Getting to know your App Cam X55



Note:

Press the **Reset/WPS** button to enable WPS.

Press and hold the **Reset/WPS** button for 10 seconds to reset the camera.


App Cam X55 Installation

Step 1: Mark and drill holes on the installation surface (wall or ceiling).


Step 2: Insert the expansion bolt into the hole.

Step 3: Fasten the installation screws to secure the device on the wall or ceiling.

Step 4: Please use a screwdriver to loosen the adjusting screw and adjust the camera to desired viewing direction and tighten back the screw.



Getting to know your App Cam X56



Note:

Press the Reset/WPS button to enable WPS.

Press and hold the Reset/WPS button for 10 seconds to reset the camera.

App Cam X56 Installation


Step 1: Mark and drill holes on the surface.

Step 2: Insert the expansion bolt into the hole.

Step 3: Fasten the screws to secure the mounting plate on the surface.

Step 4: Adjust the camera base till it sits into the installation board.

Step 5: Turn the camera base clockwise till it locks onto the installation board.



Light Indicators

For App Cam XLight/X56

LED Indicator status	Device status
Off	Powered off/LED switched off.
Solid red light	Bootting/Device malfunction/Fail to boot up.
Green light flashing	Bootting completed/ Waiting network configuration.
Solid green light	Network connection succeeded, operating normally.
Red light flashing	Network connection failure or disconnection after network connection.
Red and green lights flashing alternately	Firmware updating.

For App Cam X55




Indicate light status	Device status
Solid red light	Bootting.
Green light flashing slowly	Bootting completed/ Waiting network configuration.
Green light flashing quickly	Wi-Fi smart configuration in progress, including WPS.
Solid green light	Network connection succeeded, operating normally.
Red and green lights flashing alternately	Firmware updating.
Red light flashing slowly	Network connection failure or disconnection after network connection.
Red light flashing quickly	Device malfunction/Fail to boot up/SD card malfunction.

Set Up the Camera




Before You Start:

- Your router must support WPA2 security and it must be turned on.
- You must have an available WiFi-enabled mobile device (Android or iOS smartphone/tablet).
- The camera and your mobile device must connect to the same network router for setup.
- Please note that an upload speed of 0.5 Mbps is required for each channel remote video streaming.


1. Download and install the Guardian 365 Pro app from the Apple App Store or Google Play.
2. Connect the camera supplied power adapter. Connect the power adapter to power outlet and switch it on to supply power.
3. Open the app. The *Login* screen appears. Login if you already have an account for the app or sign up a new account and follow the instruction in the app to login.
4. The *DASHBOARD* screen displays.



5. Tap the '+' icon at the top right corner to add the camera to the app.
The *Add Device* screen displays.
6. Scan the Device ID QR code or enter the serial number of the camera manually.
7. If you already use the WPS button or an ethernet cable to connect the camera to the router, skip this step.
Enter the Wi-Fi password and follow the steps to continue. If network connection failed, tap Please try again or tap Restart to re-enter WiFi password.
8. You will need to set a new and secure password, name and time setting for the camera.
9. If you wish to add another camera, start from step 5.



You can now view video from your cameras on your smartphone.



* Please note that the app user interface and features might differ in terms of icons layout and functionality on different platforms and cameras.

Reset the Camera

To reset the App Cam XLight/X55/X56, press and hold the WPS/Reset button for 10 seconds until the light indicator is off, then only release the 'Reset' button. Refer to page 6 for light indication meaning.

Troubleshooting

If...	Try This...
The app cannot find the camera	<p>Make sure your network supports DHCP protocol.</p> <p>Make sure that the DHCP option is turned on.</p> <p>Make sure the camera and your mobile device connect to the same WiFi router.</p> <p>Make sure the WiFi router is enabled.</p> <p>Make sure the camera is properly powered on.</p> <p>Make sure the WiFi router has enabled SSID broadcasting.</p>
The camera does not find the router to connect to	<p>Make sure you selected the correct router in your device WiFi setting.</p> <p>Make sure you entered the correct password for the router you selected.</p>

As the App is constantly under development to enrich user experience, the icons/screens shown in this QSG may vary slightly from the actual app.

ONE-YEAR LIMITED WARRANTY

App Cam XLight/X55/X56

Important:

Satisfactory evidence of the original purchase is required for warranty service. Please refer to our Uniden website for any details or warranty durations offered in addition to those contained below.

Warrantor:

The warrantor is Uniden Australia Pty Limited ABN 58 001 865 498 ("Uniden Aust").

Terms of Warranty: Uniden Aust warrants to the original retail purchaser only that the App Cam XLight/X55/X56 ("the Product"), will be free from defects in materials and craftsmanship for the duration of the warranty period, subject to the limitations and exclusions set out below.

Warranty Period: This warranty to the original retail purchaser is only valid in the original country of purchase for a Product first purchased either in Australia or New Zealand and will expire one (1) year from the date of the original retail sale. If a warranty claim is made, this warranty will not apply if the Product is found by Uniden to be:

- A. Damaged or not maintained in a reasonable manner or as recommended in the relevant Uniden Owner's Manual;
- B. Modified, altered or used as part of any conversion kits, subassemblies or any configurations not sold by Uniden Aust;
- C. Improperly installed contrary to instructions contained in the relevant Owner's Manual
- D. Repaired by someone other than an authorized Uniden Repair Agent in relation to a defect or malfunction covered by this warranty; or
- E. Used in conjunction with any equipment, parts or a system not manufactured by Uniden.

Parts Covered: This warranty covers the Product and included accessories.

User-generated Data: This warranty does not cover any claimed loss of or damage to user-generated data (including but without limitation phone numbers, addresses and images) that may be stored on your Product.

Statement of Remedy: If the Product is found not to conform to this warranty as stated above, the Warrantor, at its discretion, will either repair the defect or replace the Product without any charge for parts or service. This warranty does not include any reimbursement or payment of any consequential damages claimed to arise from a Product's failure to comply with the warranty. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. This warranty is in addition to and sits alongside your rights under either the COMPETITION AND CONSUMER ACT 2010 (Australia) or the CONSUMER GUARANTEES ACT (New Zealand) as the case may be, none of which can be excluded.

Procedure for Obtaining Warranty Service: Depending on the country in which the Product was first purchased, if you believe that your Product does not conform with this warranty, you should deliver the Product, together with satisfactory evidence of your original purchase (such as a legible copy of the sales docket) to Uniden at the address shown below. You should contact Uniden regarding any compensation that may be payable for your expenses incurred in making a warranty claim. Prior to delivery, we recommend that you make a backup copy of any phone numbers, images or other data stored on your Product, in case it is lost or damaged during warranty service.

UNIDEN AUSTRALIA PTY LTD

Phone number: 1300 366 895

Email: custservice@uniden.com.au

Uniden®